



Can-am Maverick X3 Pull Plate # S3113

INSTALLATION INSTRUCTIONS

Maverick X3 Pull Plate

PARTS LIST

ITEM	PART #	DESCRIPTION	QTY
	S3113	Maverick X3 Pull Plate	1

INSTALLATION

- 1.) Place the vehicle in park and elevate the rear of the machine. Support the vehicle on suitable jack stands.
- 2.) Remove rear tires
- 3.) Remove (6) nuts securing the factory pull plate and remove the plate from the factory studs.
- 4.) Install the S3 Pull Plate onto the studs. *Note* - the studs will push in and will become out of line once the factory plate is removed. With the help of an assistant, grab the hubs and push/pull on them to help align the studs. (This can be done without help but it's a little more difficult. Have patience, work from the bottom towards the top)
- 5.) Once you start to get the studs through the pull plate, hand tighten the nuts onto the studs to secure them and prevent the stud from pulling out.
- 6.) Once you get all the nuts onto the studs, start to tighten them from left to right and from bottom to top. ***We recommend using a small amount of red Loctite***
- 7.) NOTE- if you have one already or are installing our rear bumper, leave the middle nuts off and install the bumper now.
- 8.) Reinstall wheels and tires and lower machine.
- 9.) Test drive vehicle and check all hardware.

Thank you for choosing S3 Power Sports! Let us know if you have any questions! 855-221-7097