



## 2019+ Honda Talon 2" Receiver Hitch # S3193



### INSTALLATION INSTRUCTIONS

# Honda Talon – 2” Receiver Hitch



## 2019+ Honda Talon 2" Receiver Hitch # S3193

### **PARTS LIST**

ITEM	PART #	DESCRIPTION	QTY
	S3193	2" Receiver Hitch	1
	S3BK-HTAL-P	Bolt Kit	1

### **INSTALLATION**

- 1.) Place the vehicle in park on a flat level surface.
- 2.) Remove the 4 rear inner radius rod nuts using a 17mm socket and a 17mm wrench as backup.  
(See picture A)
- 3.) Remove Bolts one at a time and replace with provided bolts, from opposite side (nut on backside of Receiver Hitch) through S3 Receiver Hitch.
- 4.) Reinstall the nuts and tighten to factory torque specs. Red threadlocker is recommended.
- 5.) Test drive vehicle and check all hardware.

Thank you for choosing S3 Power Sports! Let us know if you have any questions! 855-221-7097

