

Kawasaki Teryx KRX 1000 Winch Mount

P/N: 14022

Fits: 2020 KRX 1000

Installation Instructions:

Includes:

1. (1) Winch Plate (14022-01)
2. (1) Fairlead Plate (14022-02)

Hardware Kit:

1. (4) 3/8-16 x 1" Flange Bolts
2. (4) 3/8-16 Serrated Flange Nuts
3. (4) 3/8-16 x 3" Flange Bolts
4. (4) 3/8-16 Nylon Flange Nuts
5. (4) 3/4" Flat Washers
6. (1) Logo Sticker

Tools Needed:

1. 9/16" Socket
2. 9/16" Wrench
3. 12 mm Wrench

Accepts most Wide Spool Winches. Wide Spool Winches have a 6-5/8" x 3" Bolt Pattern.

There is a install video on our website. Look up P/N: 14022.

Installation should be done by a certified technician.

Installation:

1. Make sure the vehicle is in park.
2. Slide the winch plate behind the frame in the front and line up the four slots with the four holes in the frame.
3. Put 1-2 of the 3/4" washers around each of the frame tubes between the plate and frame. These will take up the slope. They will but up against the welds and the plate (see fig. 4).
4. Bolt the plate to the frame using the 3/8"-16 x 3" bolts and the 3/8" Nylon nuts. The bolts will go in from the front and the nuts will go on the backside. Tighten the bolts .
5. Slide your winch behind the plate you just installed. It may be easier if you jack up the front of your KRX.
6. Bolt the winch to the plate with the bolts that came with your winch.
7. Bolt the your fairlead to the fairlead bracket using the 3/8" x 1" bolts and serrated flange nuts. The nuts go on the back side and are hard to get in place but once you start the threads you can tighten them from the front.

