

EMP P/N - 13523

Can-Am Trail

Hard Coated Windshield

Fits: 2018-20 Can-Am Maverick "Trail" and "Sport"

Installation Instructions:

Includes:

1. (1) Windshield (13523-01)
2. (1) Upper Stiffener Assembly, (2-piece part, factory assembled) (13523-11 & 13523-12)

Hardware Kit:

1. (4) Thumbscrew (BR-KN6C-B7-21)
- (4) Cage Clamp (11898-02)
2. (4) 1/4-20 x 3/4" Flange Bolts-Black
3. (4) 1/4" Nyloc Flange Nut
4. (1) EMP® Logo Decal

Tools Needed:

1. 3/8" Socket or wrench
2. 7/16" Socket or wrench

Installation should be performed by a certified technician.

Installation:

1. Using the 1/4" bolts and nyloc nuts, attach the stiffener to the top of the cage. See fig.1
2. Peel the plastic film back around the edges. **NOTE: Once the protective film has been removed, this item can not be returned.**
3. Slide the top of the windshield up into the slot in the stiffener. You will have to bend/flex the polycarbonate to get it into place. See fig. 3.
4. Using the thumbscrews and cage clamps attach the windshield to the cage. See fig, 4.
5. Your installation is complete.

Fig.1



Fig. 2



Fig. 3



Fig 4

