

Maverick Trail/Sport Speed Shifter
P/N: 14001
Fits: 2018-20 Trail and 2019-20 Sport

Installation Instructions:

Includes:

1. (1) Speed Shifter

Installation should be done by a certified technician.

Hardware Kit:

No hardware required. Use stock hardware.

Tools Needed:

1. T27 Torx Bit

Installation:

1. Place wheel chocks around the tires to keep the buggy from rolling.
2. Using the Torx bit remove the stock plastic shifter shroud and save the hardware.
3. Once the hardware is removed pull the plastic back from the sides. Pull gently and the fasteners will come out.
4. Using the stock hardware install the new shifter plate. Note: The threaded clips will need to be squeezed a little to tighten them on the new shifter. In other words, the stock plastic shroud is a little thicker.
5. Test the shift pattern and make sure it shifts properly.
6. Tighten all the hardware.
7. Enjoy your American Made Product.

We Thank you for choosing Extreme Metal Products, LLC.

