

## INSTRUCTION SHEET





# UTV FLARE™ WINDSHIELD FOR POLARIS RZR

### INCLUDED COMPONENTS:

- (1) UTV Flare™ Windshield
- (1) Instruction Sheet
- (4) Axia Clamp Kits (included with standard height UTV Flare™)
- (2) Axia Clamps Kits (included with R-Spec Flare™)

### QUESTIONS?

-  EMAIL: info@getklocked.com
-  CALL: (605) 996.3700



1. Install the provided rubber trim onto the bottom edge of your UTV Flare™ Windshield
2. Follow the instructions on the Axia clamps to install all four on the front roll cage.
  - a. Remove the thumb screws and nylon washers from the clamp inserts (1)
  - b. Use the plastic bag that the clamp comes in as a powder coat guard while installing the hoop on the roll cage (2)
  - c. Loosely install the insert and finger-tighten hardware to prevent the clamps from sliding on the roll cage using the orientation shown in figure 3. (3)
3. Install your new windshield onto the Axia clamp studs
4. Final adjust clamp position as necessary to locate the studs in the windshield properly and torque the clamps on the roll cage (4)
5. Install the thumb screws and washers removed in step 1 to securely fasten the windshield to the clamps (5)

U.S. Pat No. 10,118,468

GETKLOCKED.COM