

## INSTRUCTION SHEET



### UTV FLARE™ WINDSHIELD WITH J-CLAMPS

#### INCLUDED COMPONENTS:

(1) UTV Flare™ Windshield    (1) Instruction Sheet  
(4) Axia Clamp Kits

#### QUESTIONS?



EMAIL:  
info@getklocked.com  
CALL: (605) 996.3700

1. Install the provided rubber trim onto the bottom edge of your UTV Flare™ Windshield
2. Following the provided diagram, install the clamps around the A-pillars and then through the windshield **(1)**
3. Secure the windshield clamps with the thumb screws **(2, 3)**
4. Enjoy your new UTV Flare™ Windshield!

