

INSTRUCTION SHEET



UTV FLARE™ WINDSHIELD WITH J-CLAMPS

INCLUDED COMPONENTS:

(1) UTV Flare™ Windshield (1) Instruction Sheet
(4) Axia Clamp Kits

QUESTIONS?



EMAIL:
info@getklocked.com
CALL: (605) 996.3700

1. Install the provided rubber trim onto the bottom edge of your UTV Flare™ Windshield
2. Following the provided diagram, install the clamps around the A-pillars and then through the windshield **(1)**
3. Secure the windshield clamps with the thumb screws **(2, 3)**
4. Enjoy your new UTV Flare™ Windshield!

