

Honda Talon lower door install

TOOLS NEEDED FOR INSTALL:

Drill, .250 drill bit, clamp, 7/16 wrench, 3/16 allen wrench

- 1 

REMOVE DOOR SKIN
- 2 

USE CLAMP TO HOLD LOWER DOOR TO DOOR
- 3 

MAKE SURE LOWER DOOR IS FLUSH WITH FRONT DOOR AND OUT A LITTLE FOR REAR DOOR
- 4 

DOUBLE CHECK FITMENT
- 5 

DRILL 1 HOLE .250 DIAMETER
- 6 

INSTALL SUPPLIED BOLT, WASHER ON PLASTIC SIDE
- 7 

DRILL REMAINING HOLES AND INSTALL BOLTS
- 8 

CHECK FITMENT
- 9 

REINSTALL DOOR SKIN

PLEASE GIVE @AJKOFFROAD A SHOUT OUT ON SOCIAL MEDIA AFTER INSTALL

PLEASE CONTACT AJK OFFROAD WITH ANY QUESTIONS AT : CONTACT@AJKOFFROAD.COM