



2020+ Kawasaki KRX 1000
2" Receiver Hitch # S3238



INSTALLATION INSTRUCTIONS

Kawasaki KRX 1000 2"
Receiver Hitch



2020+ Kawasaki KRX 1000

2" Receiver Hitch # S3238

PARTS LIST

PART #	DESCRIPTION	QTY
S3238	2" Receiver Hitch	1
MCS1280Z	M12x80 Bolt	2
MFW12Z	M12 Flat Washer	4
MLN12-1.75	M12 Nylock Nut	2

Tools Needed:

- Jack
- Jack Stands
- Ratchet or Impact (1/2" Drive)
- Wrenches (19mm, 17mm)
- Sockets (19mm, 17mm)

Disassembly:

- 1.) Place KRX in park (P) on a flat level surface. Engage parking brake. *(Pro Tip : For extra safety, chock front tires to prevent KRX from rolling forward.)*
- 2.) Elevate rear of machine until tires are off the ground.
- 3.) Place jack stands under frame, in suitable locations, for safety.
- 4.) Remove (4) M12 (17mm head) bolts from the rear radius rods. *(See Images 1, 2, 3)*

Assembly:

- 5.) Prepare Receiver Hitch and hardware that will be used. *(See Image 4)*
- 6.) Install stock upper bolts, through Receiver Hitch and into frame. Hand tighten only. *(Note : This will require aligning the upper radius rod with the frame holes you're using. An assistant may be helpful.)*
- 7.) Install supplied lower hardware, through Receiver Hitch and into frame. Hand tighten only. *(Note : This will require aligning the lower radius rods with the frame holes you're using. An assistant may be helpful.) (See Image 5)*
- 8.) Final tighten hardware, using red threadlocker.
- 9.) Reinstall wheels/tires, and place KRX back onto flat ground.
- 10.) Test drive and recheck all hardware/fasteners.

Thank you for choosing S3 Power Sports! Let us know if you have any questions! 855-221-7097



2020+ Kawasaki KRX 1000

2" Receiver Hitch # S3238

Image 1





2020+ Kawasaki KRX 1000

2" Receiver Hitch # S3238

Image 2





2020+ Kawasaki KRX 1000

2" Receiver Hitch # S3238

Image 3





2020+ Kawasaki KRX 1000

2" Receiver Hitch # S3238

Image 4





2020+ Kawasaki KRX 1000

2" Receiver Hitch # S3238

Image 5

