

HOW TO INSTALL AGENCY POWER WHIP LIGHT MOUNTING BRACKETS

With this quick and easy install guide, you will be able to install your Agency Power whip light mounting brackets in a matter of minutes. Installing Agency Power whip mounting brackets will allow the use of aftermarket whips and light pods on your Can-Am Maverick X3.

Tools Needed:

- T-40 Torx bit
- 13mm wrench

Installation Process:

- 1) Remove the two 13mm nuts from the backside of the cage bolts





2) With the two nuts removed, place the Agency Power whip light mounting bracket on the two protruding cage bolts



3) Thread the two nuts back on and tighten until snug





4) Install whip and/or pod light



