



motoalliance



HIGHLANDS

— C A R G O —

**Polaris RZR Pro XP / Turbo R
Cargo Box
JC11103_PXP_Xtreme**

INSTALLATION INSTRUCTIONS

Parts Included

Part #	Qty.	Item
1	1	HIGHLANDS JC11103_XP_Xtreme Cargo Box
2	2	JC_Anchor_1

INSTALLATION INSTRUCTIONS

1. Open your new HIGHLANDS Cargo Box and locate the two included quick release anchors on the side of the box.
2. Unthread the anchors slightly so that the anchors are not expanded.
3. Place the cargo box into the bed of your machine. It may take a few tries to carefully lower the box so the anchors enter into the lock and ride holes of your machine.
4. Once the box is fully seated in the bed, open the box and tighten the quick release anchors. Once adequately tightened with the lever up, press the lever down to lock the anchors in.

