

ITEM	PART#	QTY.	DESCRIPTION
1	4480-70	1	Plow Mount Plate
2	HDW9048	4	3/8" Split Lock Washer
3	HDW9029	4	3/8" USS Flat Washer
4	HDW7061	4	3/8" Nylock Nut

The studs on the mount will align with the holes in the front bumper plate as shown in picture.

Once you have place mount on machine reach around the back and place flat washers on studs first and then the lock washers and last the nylock nuts.

Align and tighten mount securely.

NOTE: Push tubes will mount with the 3/8" wire loop pins that came with the push tube kit.

Watch on how far you can lift your plow and do not over lift or you may cause severe damage to the unit and machine.





Question or Comment Call 320-964-1616 Monday thru Thursday 7:00 to 4:30 CST