



RM5 PLOW MOUNT INSTRUCTIONS
KAWASAKI BRUTE FORCE
PART# 4501-0766

ITEM	PART#	QTY.	DESCRIPTION
1	4584-70	1	Plow Mount
2	HDW9199	2	1/4 x 3/4 x 1-1/2 Rd. U-Bolt
3	HDW2150	4	5/16 x 1-1/8 x 1-3/4 Rd. U-Bolt
4	HDW7058	10	5/16 Nylock Nut
5	HDW9002	10	5/16 Flat Washer
6	HDW9199	2	1/4 x 3/4 x 1-1/2 Rd. U-Bolt
7	HDW7050	4	1/4 Nylock Nut
8	HDW9012	4	1/4 Flat Washer
9	HDW2061	2	5/16 x 1-1/4 Hex Bolt
10	4584-104	2	Fairlead Support Brackets

Install you winch mount with out fairlead .

Remove the lower front plastic skid plate.

The mount will slide into place with the back portion going between the two frame tubes and resting against a frame tube cross member. You will use the 2 – 1/4" U-bolts, washer and nylock nuts to fasten to this frame cross member as shown in lower picture.

The upper portion of the mount will be between the two bumper support arms and will attach with 2 - 5/16" U-bolts, washers and nylock nuts as shown in top picture.

The fairlead support bracket will mount to the fairlead location with the 5/16 x 1-1/4 bolts washer and nylock nuts. The upper portion of the bracket will mount to a cross member above with the 5/16 x 3/4 x 1-1/2 round U-Bolts with washer and nylock nuts.

Once all in place align and tighten securely.

NOTE: Push tubes will mount with the 3/8" wire loop pins that came with the push tube kit.

Watch how far you can lift the plow and do not over lift or you may cause severe damage to the unit or machine.

You maybe able to re-mount the lower plastic with some custom trimming.

