



**RM5 PLOW MOUNT INSTRUCTIONS**  
**HONDA RANCHER< FOREMAN, RUBICON**  
**PART# 4501-0862**

ITEM	PART#	QTY.	DESCRIPTION
1	4590-70	1	Plow Mount
2	HDW2150	4	5/16 x 1-1/8 x 1-3/4 Rd. U-Bolt
3	HDW1061	2	8mm x 30mm Hex Bolt
4	HDW7058	8	5/16 Nylock Nut
5	HDW9002	10	5/16 Flat Washer
6	HDW9428	2	5/8 x 3/8 Spacer

Remove the lower front plastic bumper cover.

It may make the mount easier if you loosen up the winch mount.

Remove the 2 lower bumper bolts now hold the mount up in place as shown and bolt the mount up to the bumper bolt location spot using the 2 – 8mm x 30mm bolts and 2 of the washers. Remember to use the spacer between mount and machine. Leave loose at this time



Attach the lower under portion to the frame tubes as shown using the 4 - u-bolts, 8 - washers and nylock nuts.

Align and tighten.

**NOTE:** Push tube will pin up with the 3/8" wire loop pins that came with the push tube kit.

Watch how far you can lift your plow and do not over lift or you may cause severe damage to the unit or machine.

You may remount the plastic skid plate but will require custom trimming.

