



**RM5 PLOW MOUNT INSTRUCTIONS
POLARIS RANGER 1000
PART# 4501-0865**

ITEM	PART#	QTY.	DESCRIPTION
1	4498-70	1	RM5 Plow Mount Plate
2	HDW1067	2	10mm-1.25 x 45mm Hex Bolt
3	HDW2060	2	5/16 x 1-1/2 Hex Bolt
4	HDW7058	2	5/16 Nylock Nut
5	HDW9002	4	5/16 SAE Flat Washer
6	HDW9406	2	5/8 rd x 5/8 lg Tube Spacer
7	HDW9441	2	1/4 thick square spacer Block

Attach to the front of machine as shown.

First remove the bottom bumper skid plate bolts just under the machine. Retain the nuts for usage when mounting RM5 plate.

Hold plate up to front of machine and attach front portion with the 5/16 x 1-1/2 hex bolts, tube spacers, washers and nylock nuts.

Place washer on bolt then slide up an into the hole in the mount. Now place tube spacer on bolt and slide through the round hole in bumper plate and secure on with washer and nylock nut.

Next hold bottom portion up in place and use the 10mm x 45mm hex bolt to go through the mount and tube spacer and into the hole you remove the bolt from and use the 10mm nut you retained to secure.

Align mount and tighten securely.

Watch on how high you can lift the plow and do not over lift as that may cause damage to plow and or machine.

Push tubes will pin up with the wire loop pins provided in the push tube kit.

