



**RM5 PLOW MOUNT INSTRUCTIONS
CAN-AM OUTLANDER
PART# 4501-0852**

PART#	QTY.	DESCRIPTION
4585-70	1	RM5 Plow Mount
HDW1056	4	8mm x 40mm Hex Bolt
HDW2061	2	5/16 x 1-1/4 Hex Bolt
HDW7058	2	5/16 Nylock Nut
HDW9002	2	5/16 Flat Washer

Attach plow mount to the front of the ATV as shown in the picture.

Attach plow mount to the four holes that the winch will be mounted to. The plow plate will bolt up to this location with the 4 – 8mm x 40mm Hex bolts going through the plow mount and the spacers and then through front of ATV and into the winch.

The bottom portion of the mount will bolt up with the 2 – 5/16 x 1-1/4 hex bolts and lock washers going through the mount and front skid plate of ATV and use the 2 – 5/16 flat washers and nylock nuts on the inside of the skid plate


Align and tighten all bolts

Some winches may use different thread pitch then the ones we provide so check to make sure the bolts go in and do not force as this may ruin the threads.

On some of the new models the lower portion of the front plastic guard may have to be trimmed off for the mount to bolt up or removed. To remove take out bottom two bolts on lower plastic guard. Now take out the lower two bumper bolts so you can pull bumper away to slide plastic guard out.

NOTE: On Renegade you will have to mark and drill the aluminum skid plate to mount plow mount up or remove for plow season.

You will replace the winch bolts on models with winch installed already.



(Align mount up with winch mounting holes)

