



**RM5 PLOW MOUNT INSTRUCTION
CAN-AM COMMANDER
PART# 4501-0822**

First you need to locate the two holes behind the front bumper and mark and drill them out through the plastic with a 3/8" drill bit. You can remove the plastic radiator side panels just by pulling them off, this will help you reach in to locate the hole and when bolting up the mount. Location is shown in picture with bolts in them.

Once the front is drilled you can bolt up the plate with the 2 - 5/16 x 1 hex bolts, 4 washer and 2 nylock nuts.

Align mount and left back portion up to skid plate. You will need to mark the inside holes for the U-Bolts and then drill them out with the 3/8" drill bit. Once drilled you can place the U-Bolt over the frame and down through the mount and secure with the remaining 5/16 washers and nylock nuts.

Don't forget to replace the inner plastic radiator panels.

The push tube will pin up to the mount with the 3/8 wire loop pins that were included with the push tube kit.

Not on how high you plow lifts when it hit the height Limit and then do not over lift or you may cause Damage to plow system or machine.

Question or Comment Call 320-964-1616
Monday thru Thursday 76:00 to 4:30 CST

ITEM	PART#	QTY.	DESCRIPTION
1	4483-70	1	RM5 Plow Mount
2	HDW2073	2	5/16 x 1-1/2 x 3-1/2 Sq. U-Bolt
3	HDW2051	2	5/16 x 1 Hex Bolt
4	HDW7058	6	5/16 Nylock Nut
5	HDW9002	8	5/16 Flat Washer

