

POWER VISION 3 MOUNT

2020 Polaris PRO XP

PARTS LIST



- | | |
|-----------------|------------------|
| 1 MOUNT BASE | 1 BOLT (6X40MM) |
| 1 EXTENSION ARM | 2 SCREW (5X18MM) |
| 1 CLAW MOUNT | |

PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION.



61300090

PRO
XP

INSTALLATION INSTRUCTIONS

Adjust the tilt steering column into its lowest position.

Using a T27, remove the torx screw on the backside of the stock gauge cluster




REMOVE STOCK SCREW

Use the supplied 6mm bolt to attach the base mount to the stock gauge cluster

Use the supplied 5mm screws to mount the extension and claw mount as shown.



INSTALL MOUNT



PUSH THE LIMIT

2191 MENDENHALL DRIVE, NORTH LAS VEGAS, NV 89081 - 800-992-4993 - DYNOJET.COM

© 2019 DYNOJET RESEARCH ALL RIGHTS RESERVED