

Polaris Ranger SP570 Rear Brushguard

P/N: 14711

Fits: 2023 Mid-Size Ranger SP570

Installation Instructions:

Includes:

1. (1) Rear Bumper
2. (2) Mtg Brackets (LH and RH)
- 3.
4. Hardware Kit:
5. (4) 5/16-18 x 1-3/4" Carriage Bolt.
6. (4) 5/16-18 Nyloc Lock Nuts
7. 3. (4) 5/16 Flat Washers
8. 4. (4) 3/8-16 x 1" Carriage Bolt (black)
9. (4) 3/8-16 Nyloc Lock Nuts
10. (4) 1/4-20 x 3/4" Hex HD Flange Bolts (black)
11. (4) 1/4-20 Nylon Nuts (black)
12. (1) Logo Sticker

Tools Needed:

1. 9/16" Wrench
2. 3/8" Wrench
3. 7/16" Wrench

Thank you for supporting
EMP®. We appreciate all of
our customers.

Installation should be done by a
certified technician.

Installation:

1. Remove the tail-gate. You have to open the tail-gate over 90 degrees then one side will slide off.
2. Install the bumper using the 5/16" bolts, washers and nuts. There should be (4) existing holes in the bed under where the tail gate was. Do not tighten yet.
3. Attach the brackets to the frame and the bumper. FYI, there are passenger and drivers side brackets. The are mirrors of each other. The top flanges will face the center of the Ranger. You will use the 3/8" Carriage bolts on the bumper end and the 1/4" bolts on the vehicle end of the brackets. There are two bolts per side per bracket. Do not tighten yet.
4. Once, you have everything in place tighten all the hardware.
5. Re-install the tailgate.

