

P/N: 14822
Fits: RZR PRO R Pack

Includes:

1. (1) Rack(14822-01)

Installation should be done by a certified technician.

Hardware Kit:

1. (4) 14656-03, Hold Down Brackets.
2. (1) 14656-02, strike Plate (3" x 5/8" Aluminum)
3. (2) 10-32 x 3/4" Phillips Pan Hd Screw.
4. (4) 1/4-20 x 3/4" Phillips Pan Hd Screw.
5. (4) 1/4-20 nylon lock flange nut
6. (2) BR-61003x1/8" C x 12" Long (Center Bubble).
7. (2) BR-61003x1/8" C x 5" Long.
8. (2) BR-61003x1/8" C x 4" Long
9. (2) BR-61003x1/8" C x 1-1/2" Long
10. (2) BR-61003x1/8" C x 2-1/2" Long
11. (4) 1/4" x 2-3/4" Coupler Pin/Bail Clips.
12. (1) Logo Sticker

Tools Needed:

1. Phillips Screwdriver
2. 7/16" Wrench

NOTE: Colors are an option. Our standard is Bare Aluminum.

Installation:

1. Slide the edge trim over the bottom edges. There are 6 total.
2. Bolt the brackets to the main assembly using the 1/4" hardware. Note the brackets should point up when it is installed.
3. Remove the factory bolts in the cargo bed area where this will attach using the supplied pins. You will not be using these anymore. This will allow tool-less removal for cleaning etc.
4. The optional nut plate is used to make some Pack Out boxes tighter. You will not believe us when we say some fit looser than others so we made it adjustable because no one would believe us. Use the nut plate if you think it needs to be tighter. It will not work with all the boxes.



