
HONDA PIONEER 700

Rear Bumper

PART #101570



| Kit Components: | | | |
|-----------------|------|--|--|
| Item # | Qty. | Description | |
| 1 | 1 | Bumper | |
| 2 | 1 | Driver Side Bumper Bracket | |
| 3 | 1 | Passenger Side Bumper Bracket | |
| 4 | 1 | Driver Side Conversion Bracket (not shown) | |
| 5 | 1 | Passenger Side Conversion Bracket | |
| 6 | 1 | Hardware Kit (HK-348) | |
| 6.1 | 6 | 5/16"-18 x .75 Carriage Bolt (Black) | |

| Kit Components: | | | |
|-----------------|------|---------------------------------------|--|
| Item # | Qty. | Description | |
| 6.2 | 2 | 5/16"-18 x .75 Hex Flange Bolt | |
| 6.3 | 8 | 5/16"-18 Hex Flange Nylock Nut | |
| 6.4 | 2 | M6-1.00 x 25 Hex Bolt | |
| 6.5 | 2 | M6 Lock Washer | |
| 7 | 1 | Hardware Kit (HK-342) | |
| 7.1 | 2 | 5/16"-18 x 1.00 Carriage Bolt (Black) | |
| 7.2 | 4 | 5/16"-18 x .75 Carriage Bolt | |
| 7.3 | 6 | 5/16"-18 Hex Flange Nylock Nut | |









INSTALLATION INSTRUCTIONS


Note: Make sure all hardware needed to complete this mount is in the package. Thoroughly read through and understand the instructions before installing.

Note: If installing lights in the bumper, cutout will accept most flush 3" cube lights. See kfiproducts.com for more details.

- 1. If you have a Pioneer 700 (2-Seater)
 - Remove bed side by removing hardware (A) as shown in **Figure 1**. Unplug brake light. Repeat for both sides.
- 2. If you have a Pioneer 700-4 (4-Seater)
 - Remove doors by removing hardware (B) as shown in **Figure 2**. Repeat for both sides.
 - Remove hardware (C) and plastic panel as shown in **Figure 3**. Repeat for both sides.
 - Remove hardware (D) as shown in **Figure 3**. Do not remove box side completely. This will allow access for the next steps. Repeat for both sides.







INSTALLATION INSTRUCTIONS

- 3. Once box side panels are removed or loose, remove the tailgate hinge hardware (E) as shown in **Figure 4**.
- 4. Remove hinge and insert through bumper bracket (2) and reinstall tailgate hinge. Loosely fasten using hardware (6.4 & 6.5) as shown in **Figure 5**.
- 5. Sesure front of bumper bracket (2) using hardware (6.2 & 6.3) as shown in **Figure 5**.
- 6. Repeat steps 3-5 for passenger side.
- 7. Place conversion bracket (4 & 5) inside of bumper (1) and secure using bolts (6.1) and nuts (6.3) as shown in **Figure 6**.
- 8. Set bumper assembly onto bumper brackets (2 & 3) and secure using bolts (7.1 & 7.2) and nuts (7.3) as shown in **Figure 6**.
- 9. Tighten all hardware evenly.

