



HIGHLANDS
— C A R G O —

Can-Am X3 Cargo Box
JC11140_X3

INSTALLATION INSTRUCTIONS

Parts Included

Part #	Qty.	Item
1	1	HIGHLANDS JC11140_X3 Cargo Box
2	4	JC_Anchor_3

INSTALLATION INSTRUCTIONS

1. Open your new HIGHLANDS cargo box and locate the four drilled holes on the bottom of the box.
2. Unthread the four included anchors and put the threaded hand knob and washer inside the box through the drilled holes.
3. Loosely re-thread the rubber section to the hand knob on the bottom side of the cargo box.
4. Place the cargo box into the bed of your machine. It may take a few tries to carefully lower the box so the anchors enter into the lock and ride holes of your machine.
5. Once the box is fully seated in the bed, open the box and tighten the hand knobs until there is no movement of the box.

