

Plow Accessory

PART #106340

Kit Components:

Item #	Qty.	Description
1	2	Pro 2.0 Pin Attachment Brackets

Note: Make sure all hardware needed to complete this mount is in the package. Thoroughly read through and understand the instructions before installing.

Note: If installing Pro 2.0 push tube #106300, replace standard pin attachment bracket with pin attachment bracket #106340 supplied in this kit.

Note: If standard pin attachment bracket has not yet been installed, skip to step 2

1. Remove standard pin attachment brackets (A) and hardware (B) as shown in **Figure 1**. **Note:** Do NOT discard hardware (B) as it will be reused.
2. Set push tube tab (1) in place and secure using hardware (B) as shown in **Figure 2**. **Note:** If standard pin attachment brackets have not already been installed, hardware (B) will be supplied with the push tubes.
3. Torque all hardware to 31 **lb-ft**.

