



HIGHLANDS
— C A R G O —

Can-Am Defender Bed Cover
JC11144_Defender

INSTALLATION INSTRUCTIONS

Parts Included

Part #	Qty.	Item
1	1	HIGHLANDS JC11144_Defender Bed Cover
2	4	JC_Anchor_5
3	2	JC_Gas_Strut

INSTALLATION INSTRUCTIONS

1. Open your new HIGHLANDS Bed Cover and locate the four holes on the base section of the cover.
2. Unthread the four included anchors and put the two rubber sections with the threaded rod through the bottom of the base and place the nut and washer on the inside of the base.
3. Loosely re-thread the nut on to the threaded rod so that the anchor assembly is secure.
4. Place the bed cover on your machine. It may take a few tries to carefully lower the cover so the anchors enter into the lock and ride holes of your machine.
5. Once the cover is fully seated in the bed, open the lid and tighten the nut while pressing down on the bed cover to ensure a tight seal.

NOTE: Using a high strength thread locker on the threaded insert in the rubber and a medium strength thread locker on the nut will aid in the anchor staying tight if you find it becoming loose over time.

6. Attach one gas strut to each side of the inside of the cover and secure the opposite ends firmly to the top of the cover.

