

**Honda Talon Wiper/Washer**  
**P/N: 14802**  
**Fits: 2020-2023 Honda Talon**

**Installation Instructions:**

**Includes:**

- (1) Wiper Motor (BR3179656)
- (1) 17" Wet Wiper Arm (BRGAR4-17")
- 13" Wiper Blade
- Wiper Harness with Switch (13766)
- (1) 2-Liter Plastic Bottle
- (1) Bottle Bracket (14802-02)
- (1) Motor Bracket (14802-01)

**Hardware Kit:**

1. (1) Paper Drill Template
2. (1) 1-1/2" Rubber Coated Strap (BRCOV2513ZI)
3. (1) Elbow for Hose (100511239JO)
4. (5) 8" Zip Ties
5. (2) M6-25 Flange Bolt (bolts for wiper motor)
6. (3) 1/4-20 Flange Head Bolts-black
7. (3) 1/4-20 Nylon Flange Nuts-black
8. (3) 1/4-20 Flat Washers-black
9. (1) 18" Rubber Washer Hose
10. (2) Blue Instant Wire Tap (31576)
11. (1) LOGO Sticker

**Tools Needed:**

1. 1-1/2" Drill (a step drill or spade drill will work)
2. 12 mm Wrench
3. T25 Torx wrench
4. 3/8" Wrench
5. 7/16" Wrench
6. 10 mm Wrench

Installation should be done by a certified technician.

**Installation:**

1. Remove the hood and the plastic panel above the hood. Save the stock screws.
2. Slide the switch into your dash. Note: you do not need to remove the switch from the harness if you do this first. Slide the wires through the hole in the dash from inside the cab area.
3. Bolt the motor to the motor bracket using the two M6 bolts provided. Set aside for now.
4. Using the template provided drill a 1-1/2" hole for the motor and a 3/8" hole for the plastic rubber tube elbow.
5. Attach the motor/bracket assembly to the two stock hood bolts. The bracket will go between the plastic and metal frame.
6. Attach the bottle to the bottle bracket using (2) 1/4-20 bolts and nuts. There is one on each side. Set the assembly aside.
7. Slide the rubber coated strap over the 1-1/4" diameter tube where the bottom of the bottle will attach.
8. Slide one end of the rubber tube over the washer bottle outlet and slide the other end over the elbow that you drilled hole for in the hood. It is easier to slide the hose through the stock plastic then slide it over the longer end of the elbow.
9. Attach top of the newly made bottle assembly to the stock bolt in the center of the hood area. Attach the bottom of the bottle to the steel tube using the remaining 1/4" hardware. It will attach to the rubber coated strap around the tube.
10. Slide the wiper arm over the motor stem and attach it with the metric nut provided.
11. You can wire connect the wiring harness directly to the battery behind the seat or cut the rings off the harness and attach it to the cigarette lighter wires using the blue wire splices. This is not plug and play at this time but will be in the near future.





