



TRAILARMOR.COM
839 HWY 2 CORINTH, MS 38834
(662) 233-5700

Installation Instructions

Installation Instructions for CAN AM MAVERICK R iMpact Trailing Arm Guards

TA012IMPTAG-CAM-R

Warnings and Product Liability Disclaimer

This product is intended to be used as a cosmetic accessory under normal equipment operation and should not be depended upon or used as a safety device. Manufacturer assumes no liability for personal injury or equipment damage as the result of use or installation of this accessory. User assumes all risk. User should carefully read all instructions prior to installation.



- A. Remove tires prior to beginning for easier install. Always secure vehicle with safety stands.
- B. Locate the Driver Side Trailing Arm Guard. Also, locate (1) #14 x 1" TEK self-drilling screw (**100054**) and (1) bowl washer (**100087**). Holding the guard into position, insert the screw and bowl washer through the pre-drilled hole shown in Picture 1 and 2.
- C. Make sure Trailing Arm is lined up and insert (4) #14 x 1" TEK self-drilling screws (**100054**) and (4) bowl washers (**100087**) into the remaining holes in the guard. See Pictures 3. Repeat for the Passenger Side. See Picture 4. Replace tires and wheels and check all lug nuts.



Picture 1



Picture 2



Picture 3



Picture 4