



TRAILARMOR.COM  
839 HWY 2 CORINTH, MS 38834  
(662) 233-5700

# Installation Instructions

## **Installation Instructions for CAN AM MAVERICK R iMPact Front Boot Guards** **TA012ARMIMPFG-CAM-R**

### **Warnings and Product Liability Disclaimer**

This product is intended to be used as a cosmetic accessory under normal equipment operation and should not be depended upon or used as a safety device. Manufacturer assumes no liability for personal injury or equipment damage as the result of use or installation of this accessory. User assumes all risk. User should carefully read all instructions prior to installation. **PLEASE NOTE:** This product was designed, fit and tested on new vehicle specifications. Any damage, modifications or excessive wear to your vehicle may require modification to the product and/or your vehicle to ensure proper fitment.



- A. Before starting the installation, remove tires and wheels and support with safety stands.
- B. Locate the Passenger Side A-arm guard (CAM-R-P). Also, locate (1) #14 x 1" TEK self-drilling screws (100054). Holding the guard into position, insert the 1" screw through the pre-drilled hole of the guard, into the factory hole in the a-arm. See Picture 1.



Picture 1



Picture 2



Picture 3

- C. Locate and install (4) #14 x 1" TEK self-drilling screws (100054). Shown in Picture 2.
- D. Repeat for the Driver side. Reinstall the wheels and tires. See Picture 3 for final install.