



HIGHLANDS
— C A R G O —

CFMoto UForce 1000 U10 Bed Cover
JC11402_CFMoto

INSTALLATION INSTRUCTIONS

Parts Included

Part #	Qty.	Item
1	1	HIGHLANDS JC11402_UForce Bed Cover
2	4	JC_Anchor_6
3	2	JC_Gas_Strut

INSTALLATION INSTRUCTIONS

1. Open your new HIGHLANDS Bed Cover and locate the four holes on the base section of the cover.
2. Remove the bolt and washer from the anchor and feed the bolt through the holes on the inside for the bed cover.
3. Loosely re-thread the bottom pieces of the anchor back onto the four bolts.
4. Place the bed cover on your machine. It may take a few tries to carefully lower the cover so the anchors enter into the connection holes of your machine.
5. Once the cover is fully seated in the bed, open the lid and tighten the bolt while pressing down on the bed cover to ensure a tight seal.

NOTE: Using a high strength thread locker on the threaded insert in the rubber and a medium strength thread locker on the bolt will aid in the anchor staying tight if you find it becoming loose over time.

6. Attach one gas strut to each side of the inside of the cover and secure the opposite ends firmly to the top of the cover.

