



TRAILARMOR.COM  
839 HWY 2 CORINTH, MS 38834  
(662) 233-5700

# Installation Instructions

## **Trail Armor Kawasaki Teryx5 H2** **iMpact Front A-Arm Guards**

TA012ARMIMPFG-KAW-TERYX5-H2

### Warnings and Product Liability Disclaimer

This product is intended to be used as a cosmetic accessory under normal equipment operation and should not be depended upon or used as a safety device. Manufacturer assumes no liability for personal injury or equipment damage as the result of use or installation of this accessory. User assumes all risk. User should carefully read all instructions prior to installation. **PLEASE NOTE:** This product was designed, fit and tested on new vehicle specifications. Any damage, modifications or excessive wear to your vehicle may require modification to the product and/or your vehicle to ensure proper fitment.



### **For Front Guards:**

- A. Locate the passenger side a-arm guard (KAW-H2-PF). Also, locate (2) supplied M6-1.0 x 25 mm bolts (**100286**). Holding the guard into position, insert the bolts through the holes of the guard, into the OEM holes. Shown in Picture 1. Loosely tighten.



Picture 1



TRAILARMOR.COM  
839 HWY 2 CORINTH, MS 38834  
(662) 233-5700

# Installation Instructions

B. Locate (3) supplied M6-1.0 x 25 mm bolts (100286) and (3) supplied bowl washers (100087). Insert one bolt and washer into the remaining OEM holes. Shown in Picture 2. Make sure the guard is properly aligned and tighten hardware.

C. Repeat Steps A and B for the driver's side. See Picture 3 for final installation.

