



RM5 PLOW MOUNT INSTRUCTIONS
 HONDA PIONEER 1000
 PART# 4501-0866

ITEM	PART#	QTY.	DESCRIPTION
1	4490-70	1	RM5 Plow Mount Plate
2	2490-3	2	Square Spacer Blocks
3	HDW1069	4	10mm-1.25 x 30mm Hex Bolt
4	HDW9008	4	7/16 SAE Flat Washer

Attach the plow mount to the bottom side of the front of the machine. There will be 4 threaded holes on the bottom front of the machine, these are threaded holes.

You will use the 4 – 10mmx 30mm hex bolt with washers to mount up to the threaded holes.

NOTE: the far back bolt will require the ¼” square spacer to go between the mount and machine as shown in bottom picture.



Once you have all 4 bolts started then tighten them up securely.

Please note on a high you can lift your plow and then do not over lift as this may cause damage to plow and or machine.

Push tube will pin up with the wire loop pins that came with the push tube kit.



Question or Comments Call 320-964-1616 Mon. thru Thur. 7:00 to 4:30 CST

INST4490PF