



INSTALLATION INSTRUCTIONS

D-SERIES[®], D-SS[™] & SR-Q SERIES[®]



THANK YOU FOR PURCHASING RIGID INDUSTRIES' PRODUCTS FOR YOUR VEHICLE.

Please read through all of these instructions and tips before proceeding with the installation. We do our best to provide a simple installation process for all applications however a professional installation is always recommended.

IMPORTANT

Always disconnect any power sources connected to your vehicle before servicing fuses or electrical systems.

WIRING INSTRUCTIONS

STEP: 1

When routing wire harness through any metal surface be sure it is free of any sharp edges and protected using wire sheathing or a grommet.

STEP: 2

Follow the WIRING DIAGRAM to ensure proper connection to switch and battery terminals.

STEP: 3

If connecting to existing wiring, make sure to use appropriate fusing and wire gauge. Be sure to use heat shrink tubing on all connections to ensure a weather tight seal.

STEP: 4


Be aware of the current rating of your selected switch, if switch rating is less than the amperage required to power your lighting then a relay must be added in line to prevent failure of the switch.

STEP: 5

Connect the positive and negative battery terminals once all connections have been made and test to verify functionality.


WIRING DIAGRAM FOR RELAY HARNESS

NOTE: GOLD Spade is the Top of Switch



WIRING DIAGRAM FOR NON-RELAY HARNESS

NOTE: GOLD Spade is the Top of Switch



*MOUNT INSTRUCTIONS & DIAGRAM FOR

D-SERIES & D-SS

1. Place 5/16"- 18 Carriage Bolt (E) into Mounting Bracket (D).
2. Use M6 Allen Socket Head (B) and M6 Nylac Nut (C) to attach Mounting Bracket (D) to Housing (A).
3. Drill a 5/16" hole into desired mounting location.
4. Use 5/16": Flat Washer (F), Lock Washer (G), and Nut (H) to secure light assembly to vehicle.
5. Tighten all hardware.

- A - LED Light (Housing)
- B - M6 Allen Socket Head (2)
- C - M6 Nylac Nut (2)
- D - Mounting Bracket
- E - 5/16"- 18 Carriage Bolt
- F - 5/16" Carriage Washer
- G - 5/16" Carriage Lock Washer
- H - 5/16"- 18 Carriage Nut



*D-Series LED Light housing shown on this Diagram.

* Bracket can be reversed for additional mounting configurations

SR-Q SERIES

1. Place 5/16"- 18 Carriage Bolt (E) into Mounting Bracket (D).
2. Use 1/4"- 20 Allen Socket Head (B) and 1/4"- 20 Nylac Nut (C) to attach Mounting Bracket (D) to Housing (A).
3. Drill a 5/16" hole into desired mounting location.
4. Use 5/16": Flat Washer (F), Lock Washer (G), and Nut (H) to secure light assembly to vehicle.
5. Tighten all hardware.

- A - LED Light (Housing)
- B - 1/4" - 20 Allen Socket Head
- C - 1/4" - 20 Nylac Nut
- D - Mounting Bracket
- E - 5/16"- 18 Carriage Bolt
- F - 5/16" Carriage Washer
- G - 5/16" Carriage Lock Washer
- H - 5/16"- 18 Carriage Nut



Your installation is now complete.
Welcome to the Rigid Nation!

WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty 779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337
www.rigidindustries.com

RIGID, SR-Q Series, D-Series, and D-SS and Rigid Industries are registered and/or common law marks owned by JST Performance, LLC, a Delaware limited liability company d/b/a Rigid Industries.

IS-D-SRQ-E